

PPS Progress Report

31.07.2025-25.08.2025

Grzegorz Jędrzejowski

25.08.2025

University of Warsaw
Faculty of Physics

Objectives

- Develop and implement analysis modules to apply physics and calibration cuts to the CTPPS Monte Carlo generated data.
- Create dedicated plotters to visualize the effects of these cuts and present key distributions.

What's Been Done?

- The analysis was performed using the modified configuration file `Validation/CTPPS/test/simu/simu_2018_cfg.py`.

Core Components

- **Producer:** `CTPPSGregDucer.cc`
- **Analyzer:** `CTPPSGregPlotter.cc`

Plotting Scripts

- `plotGreg.py`
- `plotProtons.py`
- `plotTracks.py`

Producer: Core Functionality

- Developed based on the existing framework:
`SimPPS/DirectSimProducer/plugins/PPSDirectProtonSimulation.cc`.
- Its primary function is to apply a cut to the input data (HepMC).
- The cut parameters are defined in a separate [files](#) (calibration and physics), provided by [Mario Deile](#), with the following convention:
 1. The first line specifies the number of ϕ steps, followed by their values (doubled per step).
 2. Subsequent lines define the cut specifics, starting with a ξ value, then θ_{min} and θ_{max} for each ϕ step.
- The process pipeline involves three key steps:
 - The 'getCut()' method reads the cut file.
 - The 'produce()' method processes the data and interpolates it to match the cut using 'interpolate()' and 'interpolate_step()'.
 - The 'applyCut()' method filters the data and returns the modified output.



Analyzer: Histograms and Data Flow

- Developed based on the existing framework:
`Validation/CTPPS/plugins/CTPPSProtonReconstructionPlotter.cc`.
- The analyzer is executed twice in the workflow: once before applying the cut and again after.
- The 'analyze()' method is responsible for filling a variety of histograms:
 - **1D Histograms:** ϕ , energy, p_T , and ξ .
 - **3D Histograms:** p_T - ξ - ϕ and θ - ξ - ϕ .
- These 3D histograms are later projected to create 2D histograms, which can be adjusted according to different ϕ slices.
- The analyzer saves the data in the *.root* file.


Plotting Scripts: 'plotGreg.py'

- The 'plotGreg.py' script is designed to plot and compare three datasets:
 - **Unfiltered data:** Initial data saved by the analyzer.
 - **Calibrated data:** Data processed by the producer using a calibration file and saved using the analyzer.
 - **Physics data:** Data processed by the producer using a physics file and saved using the analyzer.
- **1D Histograms:**
 - Plots three histograms (one for each dataset) side-by-side on a single canvas.
 - These are then merged into a single histogram for better visualization and comparison.
- **3D Histograms:**
 - 2D projections are created for all ϕ and plotted side-by-side.
 - For ϕ slices, 12 separate histograms are displayed on a single canvas.
- All plots are saved in '.png' format within a dedicated output directory.


Example Plots: 'plotGreg.py'



Example Plots: 'plotGreg.py'






Example Plots: 'plotGreg.py'



Plotting Scripts: 'plotProtons.py'

- The 'plotProtons.py' script is designed to access and plot data generated by 'Validation/CTPPS/plugins/CTPPSProtonReconstructionPlotter.cc'.
- It processes data from individual Roman Pot (RP) units:
 - It accesses RPs 3, 23, 103, and 123.
 - It plots the "h_xi" and "h2_th_y_vs_xi" histograms for each of these RPs.
- It also handles multi-RP data from both arms (Arm 0 and Arm 1), and for each arm, it draws the combined "h_xi" histogram.
- All plots are saved to a dedicated output directory in '.png' format.


Example Plots: 'plotProtons.py'



Plotting Scripts: 'plotTracks.py'

- The 'plotProtons.py' script is designed to access and plot data generated by 'Validation/CTPPS/plugins/CTPPSTrackDistributionPlotter.cc'.
- It processes data from individual Roman Pot (RP) units:
 - It accesses RPs 3, 23, 103, and 123.
 - It plots the "h2_y_vs_x" histogram for each of these RPs.
- All plots are saved to a dedicated output directory in '.png' format.

Example Plots: 'plotTracks.py'



Compilation and Execution Procedure

1. Set Up the Environment

- Fork the repository on GitHub.
- Create a CMSSW release: `cmsrel CMSSW_15_0_11` (or other).
- Add the required packages: `git cms-addpkg CTPPS SimPPS`.

2. Integrate the Code

- Download the files from [GitHub repository](#).
- Place the source files in the appropriate plugins directories of each package.
- Place the Python configuration files in the relevant python directories.

3. Build the Project

- In `CMSSW_15_0_11/src` build the entire project: `scram b -j 16` (or `scram b`).

4. Run the Analysis

- Navigate to the simulation directory: `cd Validation/CTPPS/test/simu/`.
- Set up the cmsenv: `cmsenv` and run the simulation: `cmsRun simu_2018_cfg.py`.
- Plot the results using the provided Python scripts, ensuring your environment can use python.

Questions?

If you have any questions, feel free to contact me:

g.jedrzejows@student.uw.edu.pl